



Southeast Floors Pty Ltd  
PO Box 784, OXENFORD QLD 4210  
Showroom: Unit 3/134 Siganto Drive, Helensvale, QLD 4212  
P: 07 5573 4837 F: 07 5502 8875  
E: [wills@southeastfloors.com.au](mailto:wills@southeastfloors.com.au)  
W: [www.southeastfloors.com.au](http://www.southeastfloors.com.au)

## EPOXY FLAKE FLOOR

### PROCEDURE

1. Grind concrete to provide a key
2. Apply a prime coat of Epoxy Resin
3. Apply a body coat of Epoxy Resin
4. Broadcast flake into the epoxy
5. Clean off the excess flake
6. Apply Polyaspartic Clear Coating

### PROCEDURE FOR PCCP SPECIFIED PROJECTS

1. Grind concrete to provide a key
2. Apply a prime coat of Epoxy Resin (APAS approved)
3. Apply a body coat of Epoxy Resin (APAS approved)
4. Broadcast flake into the epoxy
5. Clean off the excess flake
6. Apply Polyaspartic Clear Coating (APAS approved)



*Polished Concrete  
Epoxy Coatings & Sealers  
Surface Preparation  
Floor Stripping*  
QBCC Licence: 1137429